

DENON[®]

PMA-A110

INTEGRATED AMPLIFIER

Owner's Manual

[Front panel](#)[Rear panel](#)[Remote control
unit](#)[Index](#)

Accessories	4
Inserting the batteries	5
Operating range of the remote control unit	5
Part names and functions	6
Front panel	6
Rear panel	9
Remote control unit	11

Connections

Connecting speakers	14
Speaker connection	16
Connecting a playback device	17
Connecting a recording device	18
Connecting to a device with digital audio output connectors	19
Connecting a PC or Mac	20
Connecting a pre-amplifier	21
Connecting the power cord	22

Playback

Turning the power on	24
Switching the power to standby	24
Selecting the input source	25
Adjusting the volume	25
Turning off the sound temporarily (Muting)	25
Adjusting the tone and balance	25
Switching the display's brightness	26
Playing CDs	27
Connecting and playing back from a computer (USB-DAC)	28
Connecting and playing back from a digital device (Coaxial/ Optical 1/Optical 2/Optical 3)	37
Recording	38

Settings

Setting the TV Auto Play function	39
Setting the Auto Standby mode	40



Tips

Tips	42
Troubleshooting	43
Power does not turn on / Power is turned off	44
Operations cannot be performed through the remote control unit	45
Display on this unit shows nothing	45
No sound comes out	46
Desired sound does not come out	46
Sound is interrupted or noise occurs	47
Music files on PC or Mac cannot be played back	48
Audio from digital devices cannot be played back (Coaxial/ Optical)	49
The input source switches to "Optical 1", "Optical 2", "Optical 3" or "Coaxial"	49

Appendix







D/A converter	50
Explanation of terms	50
Specifications	52
Index	55



Thank you for purchasing this Denon product. To ensure proper operation, please read this owner's manual carefully before using the product. After reading this manual, be sure to keep it for future reference.

Accessories


Check that the following parts are supplied with the product.

 Quick Start Guide	 Safety Instructions	 Cautions on Using Batteries	 Power cord
 Remote control unit (RC-1237)	 R03/AAA batteries		




Inserting the batteries

- 1 Remove the rear lid in the direction of the arrow and remove it.



- 2 Insert two batteries correctly into the battery compartment as indicated.




- 3 Put the rear lid back on.

NOTE

- To prevent damage or leakage of battery fluid:
 - Do not use a new battery together with an old one.
 - Do not use two different types of batteries.
- Remove the batteries from the remote control unit if it will not be in use for long periods.
- If the battery fluid should leak, carefully wipe the fluid off the inside of the battery compartment and insert new batteries.


Operating range of the remote control unit

Point the remote control unit at the remote sensor when operating it.




Part names and functions

Front panel



For details, see the next page.





1 Power operation button (⏻)

This turns the power on/off. (👉 p. 24)

2 Power indicator

This is lit as follows according to the power status:

- Power on : White
- Standby : Off
- Power off : Off

3 Remote control sensor

This receives signals from the remote control unit. (👉 p. 5)

4 ANALOG MODE indicator

This is lit as follows, according to the analog mode status:

- Analog mode on (ANALOG MODE 1 or 2): White
- Analog mode off: Off

5 ANALOG MODE button

This switches the ANALOG MODE 1/2/off. (👉 p. 27)

6 SOURCE DIRECT indicator

This is lit as follows according to the source direct status:

- Source direct mode on: White
- Source direct mode off: Off

7 SOURCE DIRECT button

This turns source direct mode on/off. (👉 p. 27)

8 MC/MM indicator

This is lit as follows according to the setting of the phono equalizer of this unit:

- MC: White
- MM: Off


9 MC/MM button

This switches to MC or MM according to the type of cartridge used on your turntable.

10 Volume knob

This adjusts the volume level. (👉 p. 25)





11 Display

This displays information such as the input source name, type of digital audio signal and sampling frequency.

12 Input source select knob

This selects the input source. (👉 p. 25)

NOTE

- When you set this unit's input source to "EXT.PRE", the main unit outputs at maximum volume. Also adjustment of the volume balance and tone on the main unit has no effect. Adjust the volume on the inputting devices before playback.

13 Headphones jack (PHONES)

Used to connect headphones.

When the headphones are plugged into this jack, audio will no longer be output from the speaker terminals.

NOTE

- To prevent hearing loss, do not raise the volume level excessively when using headphones.

14 BASS control knob

This setting adjusts the volume level for the bass. (👉 p. 25)

15 TREBLE control knob

This setting adjusts the volume level for the treble. (👉 p. 25)

16 BALANCE control knob


This adjusts the balance of the volume output from the left and right speakers. (👉 p. 25)



- 14, 15 and 16 can be adjusted when 6 is off (Source direct mode is off).




Rear panel



For details, see the next page.





1 Analog audio connectors (AUDIO IN)

Used to connect devices equipped with analog audio connectors.

- “Connecting a playback device” (☞ p. 17)
- “Connecting a recording device” (☞ p. 18)

2 SIGNAL GND terminal

Used to connect the ground wire of a turntable. (☞ p. 17)

3 Speaker terminals (SPEAKERS)

Used to connect speakers. (☞ p. 14)

4 AUDIO OUT connectors

Used to connect the input connector of a recorder. (☞ p. 18)

5 EXT.PRE IN connectors

Used to connect a pre-amplifier when this unit is used as a power amplifier. (☞ p. 21)

The volume should be adjusted on the connected device.

6 DIGITAL AUDIO IN connectors

Used to connect devices equipped with digital audio output connectors and computer.

- “Connecting to a device with digital audio output connectors” (☞ p. 19)
- “Connecting a PC or Mac” (☞ p. 20)

7 IR CONTROL connectors


Used to connect Denon network audio players with an IR controller.

8 AC inlet (AC IN)

Used to connect the power cord. (☞ p. 22)



Remote control unit



The remote control provided with this unit can control a Denon CD player.

- “CD player operations” (☞ p. 12)

■ Operating this unit

1 Remote control signal transmitter

This transmits signals from the remote control unit. (☞ p. 5)

2 Power operation button (AMPLIFIER)

This turns the power on/off (standby). (☞ p. 24)

3 TV AUTO-PLAY button

This switches the digital input for the TV auto play. (☞ p. 39)

4 ANALOG MODE button

This switches the analog mode 1/2/off. (☞ p. 27)

5 MUTE button

This mutes the output audio. (☞ p. 25)

6 VOLUME buttons (▲▼)

These adjust the volume level. (☞ p. 25)

7 DIMMER button

This switches the brightness of the display. (☞ p. 26)

8 INPUT SELECT buttons

This selects the input source. (☞ p. 25)




CD player operations

A Denon CD player can be operated.

- 1 Power operation button (⏻)
- 2 DISC LAYER button
- 3 Cursor buttons (⬆️⬇️⬇️⬆️)
- 4 ENTER button
- 5 Number buttons (0 - 9, +10)
- 6 RANDOM button
- 7 REPEAT button
- 8 System buttons (⏮️⏪️⏩️⏭️)
- 9 DIMMER button
- 10 MODE button
- 11 CLEAR button
- 12 PROGRAM button
- 13 Information button (INFO)



- The remote control may not operate some products.



■ Contents


Connecting speakers	14
Connecting a playback device	17
Connecting a recording device	18
Connecting to a device with digital audio output connectors	19
Connecting a PC or Mac	20
Connecting a pre-amplifier	21
Connecting the power cord	22

NOTE

- Do not plug in the power cord until all connections have been completed.
- Do not bundle power cords together with connection cables. Doing so can result in humming or noise.

■ Cables used for connections

Provide necessary cables according to the devices you want to connect.



Connecting speakers

NOTE

- Disconnect this unit's power plug from the power outlet before connecting the speakers.
- Connect so that the speaker cable core wires do not protrude from the speaker terminal. The protection circuit may be activated if the core wires touch the rear panel or if the + and - sides touch each other. ("Protection circuit" (👉 p. 51))
- Never touch the speaker terminals while the power cord is connected. Doing so could result in electric shock.
- Use speakers with an impedance of 4 – 16 Ω /ohms.


■ Connecting the speaker cables

Carefully check the left (L) and right (R) channels and + (red) and - (white) polarities on the speakers being connected to this unit, and be sure to connect the channels and polarities correctly.


- 1 Peel off about 10 mm of sheathing from the tip of the speaker cable, then either twist the core wire tightly or terminate it.**




- 2 Turn the speaker terminal counterclockwise to loosen it.**




- 3 Insert the speaker cable's core wire to all the way into the speaker terminal.**




4 Turn the speaker terminal clockwise to tighten it.



Spade lug connector




Speaker connection



Connecting a playback device

You can connect turntables, CD players and network audio players to this unit.

If you set this unit's input source to "PHONO" and you accidentally increase the volume without having a turntable connected, you may hear a hum noise from the speakers.



NOTE


- The earth terminal (SIGNAL GND) of this unit is not for safety grounding purposes. If this terminal is connected when there is a lot of noise, the noise can be reduced. Note that depending on the turntable, connecting the ground line may have the reverse effect of increasing noise. In this case, it is not necessary to connect the ground line.



- The PHONO input terminals are equipped with a short pin-plug. Remove this plug to connect a record player. Store the removed short pin-plug in a safe place so as not to lose it.



Connecting a recording device




NOTE

- Never insert the short-circuiting pin plug into the recording output connectors (AUDIO OUT RECORDER). Doing so could result in damage.



Connecting to a device with digital audio output connectors

Use this connection to input digital audio signals to this unit, and convert the signals for playback using the D/A converter of this unit. (📖 p. 28)



NOTE

- Linear PCM signals with a sampling frequency of 32 kHz, 44.1 kHz, 48 kHz, 88.2 kHz, 96 kHz, 176.4 kHz, or 192 kHz can be input into this unit.
- Do not input non-PCM signals, such as Dolby Digital, DTS and AAC. This causes noise and could damage the speakers.




Connecting a PC or Mac


By connecting a computer to the USB-DAC port on the rear panel of this unit using a commercially available USB connecting cable, this unit can be used as a D/A converter. (👉 p. 28)

NOTE

- Before USB connecting this unit to your computer, install the driver software in your computer. (👉 p. 29)
- Download the driver software from the PMA-A110 page of the Denon website.
- Use a cable that is 3 m or less to connect to the computer.



Connecting a pre-amplifier




- The EXT.PRE input terminals are equipped with a short pin-plug. Remove this plug to connect a pre-amplifier. Store the removed short pin-plug in a safe place so as not to lose it.



Connecting the power cord



After completing all the connections, insert the power plug into the power outlet.



■ Contents

Turning the power on	24
Switching the power to standby	24
Selecting the input source	25
Adjusting the volume	25
Turning off the sound temporarily (Muting)	25
Adjusting the tone and balance	25
Switching the display's brightness	26
Playing CDs	27
Connecting and playing back from a computer (USB-DAC)	28
Connecting and playing back from a digital device (Coaxial/Optical 1/Optical 2/Optical 3)	37
Recording	38





Turning the power on

1 Press \odot on the main unit to turn the power on.

The power indicator lights white.



- Press AMPLIFIER \odot on the remote control unit to turn on power from standby mode.

NOTE

- Turn volume knob on the main unit to adjust the volume to the lowest level before turning on the power.

Switching the power to standby

1 Press AMPLIFIER \odot .

The unit switches to standby mode.

NOTE

- Power continues to be supplied to some of the circuitry even when the power is in the standby mode. When leaving home for long periods of time or when going on vacation, either press \odot on the main unit to turn off the power, or unplug the power cord from the power outlet.



Selecting the input source

- 1 Press **INPUT SELECT** to select the input source to be played.

The selected input source is displayed on the display of this unit.



- You can also select the input source by turning input source select knob on the main unit.

Adjusting the volume

- 1 Press **VOLUME ▲▼** to adjust the volume.



- You can also adjust the volume by turning volume knob on the main unit.

Turning off the sound temporarily (Muting)

- 1 Press **MUTE**.

“MUTE” is displayed on the display of this unit.



- To cancel mute, either adjust the sound volume or press MUTE again.

Adjusting the tone and balance

- 1 Press **SOURCE DIRECT** on the main unit to turn off source direct mode.
The SOURCE DIRECT indicator turns off.
- 2 Turn the **BASS**, **TREBLE** and **BALANCE** on the main unit to adjust the tone and balance.



Switching the display's brightness

The display brightness can be adjusted between four levels. Switching the display off reduces a source of noise that affects sound quality, enabling higher sound quality playback.

1 Press DIMMER.

- The brightness of the display switches each time the button is pressed.



- The display brightness is set to most brightly by default.
- The DIMMER button also controls the Denon's Super Audio CD Player DCD-A110, so the DCD-A110 can be operated simultaneously with this unit. When the two units have different settings, press and hold in the button for lease 2 seconds to reset them both to the default setting, then make the desired setting.



Playing CDs

This section uses playback from a CD as an example.

1 Press INPUT SELECT to switch the input source to “CD”.

“CD” is displayed on the display of this unit.

2 Playback the CD.

3 Press VOLUME ▲▼ to adjust the volume.

■ Playback in source direct mode

The signal does not pass through the tone adjustment circuitry (BASS, TREBLE and BALANCE), resulting in playback of a higher sound quality.

1 Press SOURCE DIRECT on the main unit to turn on source direct mode.

The SOURCE DIRECT indicator lights.

■ Playback in analog mode

When the analog mode is turned on to playback an analog source (PHONO, CD, NET/AUX, RECORDER, EXT.PRE), power to the digital input circuit and the display turn off. This enables you to enjoy high sound quality audio playback without sound quality being affected by noise that occurs from the digital control circuit.

1 Press ANALOG MODE to turn analog mode on.

The ANALOG MODE indicator lights.

- Press ANALOG MODE to toggle between “ANALOG MODE Off”, “ANALOG MODE 1” and “ANALOG MODE 2”.

ANALOG MODE Off:	Analog mode is not used.
ANALOG MODE 1:	Turns the digital input circuit power off.
ANALOG MODE 2:	Turns the digital input circuit power and display off.



- A digital input source (COAXIAL, OPTICAL 1/2/3, USB-DAC) cannot be selected when analog mode is on.
- The input source automatically switches to CD if analog mode is turned on during playback of a digital input source (COAXIAL, OPTICAL 1/2/3, USB-DAC).
- Communication between this unit and the computer is disconnected if analog mode is turned on when a computer is connected to the USB-DAC input connector of this unit. If the unit cannot communicate with the computer after turning analog mode off again, disconnect and reconnect the USB cable or restart the audio player on the computer.
- When the analog mode is switched, the mute circuit is activated for about 5 seconds.



Connecting and playing back from a computer (USB-DAC)

You can enjoy high-quality audio playback from the D/A converter built in to this unit by inputting music files into this unit from a computer via USB connection.

- Before USB connecting this unit to your computer, install the driver software in your computer.
- Drivers do not need to be installed for macOS.
- Also, you can use whichever commercially available or downloadable player software you like to playback files on your computer.

■ Computer (system requirements)

OS

- Windows 8.1 or Windows 10
- macOS 10.13, 10.14 or 10.15

USB

- USB 2.0: USB High speed/USB Audio Class Ver. 2.0

NOTE

- This unit was checked the operation using the system requirements by us, but it does not guarantee the operation of all systems.

- DSD is a registered trademark.
- Microsoft, Windows 8.1 and Windows 10 are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- ASIO is a trademark of Steinberg Media Technologies GmbH.
- Apple, Macintosh and macOS are trademarks of Apple Inc., registered in the U.S. and other countries.

Windows
OS

Installing the dedicated driver (👉 p. 29)

macOS

Audio Device Settings (👉 p. 35)




■ Installing the dedicated driver (Windows OS only)

□ Installing the driver software


- 1 Disconnect the USB cable between your PC and the unit.**
 - The driver software cannot be installed correctly if your PC is connected to the unit by a USB cable.
 - If the unit and your computer are connected by a USB cable and the computer is switched on before installation, disconnect the USB and restart the computer.
- 2 Download the dedicated driver from the “Download” section of the PMA-A110 page of the Denon website onto your PC.**
- 3 Unzip the downloaded file, and double-click the exe file.**

4 Install the driver.

- ① Select the language to use for the installation.
- ② Click “OK”.




- ③ The wizard menu is displayed. Click “Next”.




- ④ Read the Software Licensing Agreement, and click “I accept the terms of the License Agreement”.
- ⑤ Click “Next”.




- ⑥ Click “Install” on the installation start dialog.
- The installation starts. Do not perform any operation on the PC until the installation is completed.




- ⑦ Click “Next”.



- ⑧ When the installation is completed, click “Finish”.



- ⑨ Click “Yes”.



5 With the unit power off, connect the unit and PC using a USB cable (sold separately).

- For details on connections, see “Connecting a PC or Mac” (📖 p. 20).



6 Press ϕ on this unit.

- When the unit power is turned on, the PC automatically finds and connects to the unit.

7 Press INPUT SELECT to switch the input source to “USB-DAC”.


8 Checking the installed driver.

- ① Click the “Start” button and click “Control Panel” on the PC.
 - The control panel setting list is displayed.
- ② Click “Sound”.
 - The sound menu window is displayed.
- ③ Check that there is a checkmark next to “Default Device” under in “PMA-A110” of the “Playback” tab.
 - When there is a checkmark for a different device, click “PMA-A110” and “Set Default”.


9 Checking audio output.

Outputs a TEST signal from the PC and checks the audio output from the USB-DAC function.

- ① Select “PMA-A110” and click “Properties”.
 - The Properties window is displayed.



- ② Click the “Advanced” tab.
 - ③ Select the sampling rate and bit rate to be applied to the D/A converter.
 - It is recommended that “2 channel, 32 bit, 192000 Hz (Studio Quality)” is selected.
 - ④ Click “Apply”.
 - ⑤ Click “Test”.
- Check that audio from this unit is output from the PC.




NOTE

- The dedicated driver must be installed in the PC before this unit is connected to a PC. Operation will not occur correctly if connected to the PC before the dedicated driver has been installed.
- Operation may fail in some PC hardware and software configurations.
- Player software supporting the Audio Stream Input Output (ASIO) driver is required to play files with a sampling frequency of 352.8 kHz/384 kHz without downsampling. Check your player software before playing files with the ASIO driver.
- Please see the FAQ at www.denon.com if you experience any issues getting audio to play from your computer through this unit. You may also want to check the support pages for your audio player application.




■ Audio Device Settings (macOS only)

- ① With the unit power off, connect the unit and Mac using a USB cable (sold separately).
 - For the connection procedure, refer to the “Connecting a PC or Mac” section. (👉 p. 20)
- ② Press \odot .
- ③ Press INPUT SELECT to switch the input source to “USB-DAC”.
- ④ Move the cursor to “Go” on the computer screen, and then click “Utilities”.
 - The utility list is displayed.
- ⑤ Double-click “Audio MIDI Setup”.
 - The “Audio Devices” window is displayed.
- ⑥ Check that “Use this device for sound output” is checked in “PMA-A110”.
 - If a different device is checked, select and “Secondary click” on “PMA-A110”, and then select “Use this device for sound output”.



- ⑦ Select the “PMA-A110” format.
- It is normally recommended to set the format to “384000.0 Hz” and “2ch-32 bit Integer”.



- ⑧ Quit Audio MIDI Setup.

■ Playback

Install the desired player software on your computer beforehand. Use the rear panel USB-DAC port to connect this unit to a computer. (☞ p. 20)

1 Press INPUT SELECT to switch the input source to “USB-DAC”.

Start playback on the computer’s player software.

- If the sampling frequency cannot be detected, “Unlocked” will be displayed.
- “Unsupported” is displayed when audio signals that are not supported by this unit are input.



■ Specifications of supported audio formats

See “D/A converter” (📖 p. 50).

NOTE

- Perform operations such as playback and pause on the computer. At this time, you cannot perform operations with buttons on this unit or the remote control.
- When this unit is functioning as a D/A converter, sound is not output from the computer's speakers.
- If the computer is disconnected from this unit while the computer music playback software is running, the playback software may freeze. Always exit the playback software before disconnecting the computer.
- When an error occurs on the computer, disconnect the USB cable and restart the computer.
- The sampling frequency of the music playback software and sampling frequency displayed on this unit may differ.
- Use a cable that is 3 m or less to connect to the computer.

Connecting and playing back from a digital device (Coaxial/Optical 1/Optical 2/Optical 3)

- 1 Connect digital device to this unit.** (📖 p. 19)
- 2 Press INPUT SELECT to switch the input source to “COAXIAL” or “OPTICAL 1/2/3”.**
 - If the sampling frequency cannot be detected, “Unlocked” will be displayed.
 - “Unsupported” is displayed when audio signals that are not supported by this unit are input.

■ Specifications of supported audio formats

See “D/A converter” (📖 p. 50).


NOTE

- Do not input non-PCM signals, such as Dolby Digital, DTS and AAC. This causes noise and could damage the speakers.



Recording

Audio signals input into this unit can be output to an external recording device. When recording audio from a playback device connected to this unit, audio can be recorded with the playback device still connected to this unit.


- 1 Press  on the main unit to turn the power on.**
- 2 Press INPUT SELECT to switch to the input source from which you want to record.**

The selected input source is displayed on the display of this unit.
- 3 Recording starts.**
 - For information on operations, see the owner's manual of the recording device.



Setting the TV Auto Play function

Set this when playing audio from a TV on this unit. When the TV is turned on, this unit turns on and the input source is automatically switched to “OPTICAL 1”, “OPTICAL 2”, “OPTICAL 3” or “COAXIAL” so that the audio from the TV can be played through this unit. Set this according to the connector on this unit where the TV is connected.



1 Press TV AUTO-PLAY to select the setting.

- The setting changes each time TV AUTO-PLAY is pressed.

OPTICAL 1 / OPTICAL 2 / OPTICAL 3 / COAXIAL / Off
(Default: OPTICAL 1)




- When the analog mode is set to “ANALOG MODE 1” or “ANALOG MODE 2”, the TV Auto Play function does not work. (p. 27)
- Depending on your TV, the TV Auto Play function may not work.
- This unit will not automatically turn off when the TV is turned off.



Setting the Auto Standby mode

You can set the unit to automatically switch to standby mode if the unit is not operated for 30 minutes when there is no audio input (Auto Standby mode).

Auto Standby mode is set to on by default.



1 Press and hold **AMPLIFIER** for 5 seconds or more to switch it on and off.

The display changes as follows each time it is switched on and off.

- When auto standby mode is on: "AutoStby On" is displayed.
- When auto standby mode is off: "AutoStby Off" is displayed.



■ Contents

Tips

I want to adjust the tone myself	42
I want sound playback that is faithful to the original sound	42
I want to enjoy higher sound quality from the analog input source	42
I want to use this unit as a power amplifier	42

Troubleshooting

Power does not turn on / Power is turned off	44
Operations cannot be performed through the remote control unit	45
Display on this unit shows nothing	45
No sound comes out	46
Desired sound does not come out	46
Sound is interrupted or noise occurs	47
Music files on PC or Mac cannot be played back	48
Audio from digital devices cannot be played back (Coaxial/Optical)	49
The input source switches to “Optical 1”, “Optical 2”, “Optical 3” or “Coaxial”	49



Tips

I want to adjust the tone myself

- Use the BASS, TREBLE and BALANCE knobs to adjust the sound as desired. (👉 p. 25)

I want sound playback that is faithful to the original sound

- Set the source direct mode on. (👉 p. 27)

I want to enjoy higher sound quality from the analog input source

- Set the analog mode on. (👉 p. 27)

I want to use this unit as a power amplifier

- Connect the pre amplifier to the EXT.PRE IN connectors of this unit. (👉 p. 21)



Troubleshooting

If a problem should arise, first check the following:

1. **Are the connections correct?**
2. **Is the set being operated as described in the owner's manual?**
3. **Are the other devices operating properly?**

If this unit does not operate properly, check the corresponding symptoms in this section.

If the symptoms do not match any of those described here, consult your dealer as it could be due to a fault in this unit. In this case, disconnect the power immediately and contact the store where you purchased this unit.



Power does not turn on / Power is turned off

Power is not turned on.

- Check whether the power plug is correctly inserted into the power outlet. (👉 p. 22)

Power automatically turns off.

- The Auto Standby mode is on. When approx. 30 minutes pass with no audio input and no operations on the unit, this unit automatically enters the standby mode. To turn off the Auto Standby mode, press the AMPLIFIER ⏻ button for 5 seconds or longer. (👉 p. 40)

The power turns off and the power indicator shows one long blink and two short blinks in red.

- Stop playback on the playback device, and then turn the power off and on again.
- If the problem is not solved by turning the power off and on again, this unit's amplifier circuit has failed. Unplug the power cord and contact our customer service center.

The power turns off and the power indicator shows one long blink and three short blinks in red.

- This unit's power circuit has failed. Unplug the power cord and contact our customer service center.

The power turns off and the power indicator shows one long blink and four short blinks in red.

- The protection circuit has been activated due to a rise in temperature within this unit. Turn the power off, wait about an hour until this unit cools down sufficiently, and then turn the power on again.
- Please re-install this unit in a place having good ventilation.
- Check the speaker connections. The protection circuit may have been activated because speaker cable core wires came in contact with each other or a core wire was disconnected from the connector and came in contact with the rear panel of this unit. After unplugging the power cord, take corrective action such as firmly re-twisting the core wire or taking care of the connector, and then reconnect the wire. (👉 p. 14)
- Stop playback on the playback device, and then turn the power off and on again.

The power turns off and the power indicator shows one long blink and five short blinks in red.

- Stop playback on the playback device, and then turn the power off and on again.
- If the problem is not solved by turning the power off and on again, this unit's amplifier circuit or power circuit has failed. Unplug the power cord and contact our customer service center.



Operations cannot be performed through the remote control unit

Operations cannot be performed through the remote control unit.

- Batteries are worn out. Replace with new batteries. (👉 p. 5)
- Operate the remote control unit within a distance of about 7 m from this unit and at an angle of within 30°. (👉 p. 5)
- Remove any obstacle between this unit and the remote control unit.
- Insert the batteries in the proper direction, checking the ⊕ and ⊖ marks. (👉 p. 5)
- The set's remote control sensor is exposed to strong light (direct sunlight, inverter type fluorescent bulb light, etc.). Move the set to a place in which the remote control sensor will not be exposed to strong light.
- When using a 3D video device, the remote control unit of this unit may not function due to effects of infrared communications between units (such as TV and glasses for 3D viewing). In this case, adjust the direction of units with the 3D communications function and their distance to ensure they do not affect operations from the remote control unit of this unit.

Display on this unit shows nothing

Display is off.

- Press the DIMMER button, and change the setting to anything other than off. (👉 p. 26)
- The analog mode is set to "ANALOG MODE 2". Press the ANALOG MODE button to set the analog mode to "ANALOG MODE 1" or "ANALOG MODE Off". (👉 p. 27)



No sound comes out

No sound comes out of speakers.

- Check the connections for all devices. (🔗 p. 13)
- Insert connection cables all the way in.
- Check that input connectors and output connectors are not reversely connected.
- Check cables for damage.
- Check that speaker cables are properly connected. Check that cable core wires come in contact with the metal part on speaker terminals. (🔗 p. 14)
- Securely tighten the speaker terminals. Check speaker terminals for looseness. (🔗 p. 14)
- Check that the proper input source is selected. (🔗 p. 25)
- The volume is set to the minimum level. Adjust the volume to a suitable level. (🔗 p. 25)
- Cancel the muting mode. (🔗 p. 25)
- No sound is output from the speakers when headphones are connected. (🔗 p. 8)

Desired sound does not come out

No sound comes out of a specific speaker.

- Check that speaker cables are properly connected. (🔗 p. 14)
- Adjust the BALANCE control knob. (🔗 p. 25)

The left and right of stereo sound is reversed.

- Check whether the left and right speakers are connected to the correct speaker terminals. (🔗 p. 16)



Sound is interrupted or noise occurs

When playing a record, the sound is distorted.

- Adjust to a proper needle pressure.
- Check the tip of the needle.
- Replace the cartridge.

When playing a record, a humming noise comes out of the speakers.

- Check that the turntable is connected correctly. (👉 p. 17)
- If there is a TV or AV device near the turntable, such devices may affect the playback sound. Install the turntable in a location as far away as possible from the TV or other AV devices.

When playing a record, a humming noise comes out of the speakers when the volume is high. (Howling phenomenon)

- Install the turntable and speakers as far from each other as possible. (👉 p. 17)
- The vibrations from the speakers are being transmitted to the player through the floor. Use cushions, etc., to absorb the speakers' vibrations.

Sound is interrupted during playback of tracks saved on a computer.

- Do not start applications other than the player software while playing music on your computer.



Music files on PC or Mac cannot be played back

This unit is not recognized on the computer.

- Reconnect the USB cable to the USB port on your computer. When this unit is still not recognized after reconnection, connect to a different USB port. (👉 p. 20)
- Restart your computer.
- Check the OS of your computer. (👉 p. 28)
- When your computer is running on Windows, a dedicated driver software should be installed. (👉 p. 29)

This unit is not selected as the playback device.

- Select this unit as the playback device in the sound settings on the computer. (👉 p. 28)

“Unlocked” is displayed.

- When digital audio signals cannot be detected properly, “Unlocked” is displayed. (👉 p. 36)

“Unsupported” is displayed.

- “Unsupported” is displayed when audio signals that are not supported by this unit are input. Check the settings on your computer or player software. (👉 p. 36)
- If the computer you use is macOS, please check if the PMA-A110 format is set below 384000.0 Hz using the Audio MIDI Setup. (👉 p. 35)



Audio from digital devices cannot be played back (Coaxial/Optical)

“Unlocked” is displayed.

- When digital audio signals cannot be detected properly, “Unlocked” is displayed. (👉 p. 37)

“Unsupported” is displayed.

- “Unsupported” is displayed when audio signals that are not supported by this unit are input. Check the audio output signal format from your digital device. (👉 p. 37)

The input source switches to “Optical 1”, “Optical 2”, “Optical 3” or “Coaxial”

The input source automatically switches to “Optical 1”, “Optical 2”, “Optical 3” or “Coaxial” when the TV connected to this unit is turned on.

- Press the TV AUTO-PLAY button on the remote control unit to set the TV Auto Play function to “Off”. (👉 p. 39)



D/A converter

■ Specifications of supported audio formats

□ USB-DAC

	Sampling frequency	Bit length
DSD (2-channel)	2.8/5.6/11.2 MHz	1 bit
Linear PCM (2-channel)	44.1/48/88.2/96/176.4/ 192/352.8/384 kHz	16/24/32 bits

□ Coaxial/Optical

	Sampling frequency	Bit length
Linear PCM (2-channel)	32/44.1/48/88.2/96/ 176.4/192 kHz	16/24 bits

Explanation of terms

DSD (Direct-Stream Digital)

One of the audio data recording methods, it is the signal aspect used to store audio signals on a super audio CD, and is Δ - Σ modulated digital audio. It is configured of an array of single bit values at a 2.8 MHz sampling rate.

Sampling frequency

Sampling involves taking a reading of a sound wave (analog signal) at regular intervals and expressing the height of the wave at each reading in digitized format (producing a digital signal). The number of readings taken in one second is called the “sampling frequency”. The larger the value, the closer the reproduced sound is to the original.

Linear PCM

This is an uncompressed PCM (Pulse Code Modulation) signal. This is the same system used for CD audio but uses 192 kHz, 96 kHz, and 48 kHz sampling frequencies on Blu-ray Disc or DVD and provides higher resolution than CD.



Speaker impedance

This is an AC resistance value, indicated in Ω (ohms).

Greater power can be obtained when this value is smaller.

Source direct

Playback with higher fidelity to the source becomes possible, as input audio signals are output by bypassing the audio quality-control circuits (BASS/TREBLE/BALANCE).

Protection circuit

This is a function to prevent damage to devices within the power supply when an abnormality such as an overload, excess voltage occurs or over temperature for any reason.



Specifications

■ Power amplifier section

Rated Output Power:	2-channel driving (CD → SP OUT) 80 W + 80 W (8 Ω/ohms, 20 Hz - 20 kHz, T.H.D. 0.07 %) 160 W + 160 W (4 Ω/ohms, 1 kHz, T.H.D. 0.7 %)
Total harmonic distortion:	0.01 % (Rated output: -3 dB), 8 Ω/ohms, 1 kHz
Output terminals:	Speaker: 4 – 16 Ω/ohms Suited for headphones/stereo headphones
Input Sensitivity/Input Impedance:	EXT.PRE: 0.9 V / 47 kΩ/kohms Amplification factor: 29 dB

■ Pre amplifier section

Input Sensitivity/Input Impedance:	PHONO (MM): 2.5 mV / 47 kΩ/kohms PHONO (MC): 200 μV / 100 Ω/ohms CD, NETWORK/AUX, RECORDER: 135 mV / 19 kΩ/kohms
RIAA Deviation:	PHONO: 20 Hz – 20 kHz ±0.5 dB
Maximum Input:	PHONO (MM): 130 mV / 1 kHz PHONO (MC): 10 mV / 1 kHz



■ Overall performance

SN Ratio (A network):	PHONO (MM): 84 dB (With input terminals short-circuited, 5 mV input signal) PHONO (MC): 72 dB (With input terminals short-circuited, 0.5 mV input signal) CD, NETWORK/AUX, RECORDER: 101 dB (input terminals short-circuited)
Frequency response:	5 Hz – 100 kHz (0 – -3 dB)
Tone control:	BASS: 100 Hz \pm 8 dB TREBLE: 10 kHz \pm 8 dB

Digital input signal formats

- **Format:** Digital audio interface (Linear PCM)
- **Coaxial input:** 0.5 V_{p-p} / 75 Ω /ohms
- **Optical input:** More than -27 dBm
- **Optical wavelength:** 660 nm


■ General

Operating temperature:	+5 °C - +35 °C
Power supply:	AC 230 V, 50/60 Hz
Power consumption:	400 W
Power consumption in standby modes	
• TV Auto Play setting - Enabled:	0.4 W
• TV Auto Play setting - Disabled:	0.2 W

For the purpose of improvement, the specifications and design are subject to change without notice.



■ Dimensions (Unit : mm)



■ Weight: 25.0 kg



Index

A		
Auto Standby mode	40	
B		
BALANCE	25	
BASS	25	
BD player	17	
C		
CD player	17, 19	
D		
D/A Converter	28	
I		
Input source	25	
Install the driver	29	
M		
Muting	25	
N		
Network audio player	17	
P		
PC	20	
Pre-amplifier	21	
Protection circuit	51	
R		
Recording device	18	
Remote control unit	11	
S		
Satellite receiver	19	
Source direct	27, 51	
Speaker impedance	51	
Speakers	14	
T		
Tips	42	
Tone	25	
TREBLE	25	
Troubleshooting	43	
Turntable	17	
U		
USB-DAC	28	
V		
Volume	25	



DENON[®]

www.denon.com

3520 10779 00AD

© 2020 Sound United. All Rights Reserved.